

# Transport Box Operators manual



Kilworth Machinery Ltd., Annwell Lane, Smisby, Ashby de la Zouch LE65 2TA  
Tel: 01530 412690 Fax: 01530 560002 Email: [sales@kilworthmachinery.co.uk](mailto:sales@kilworthmachinery.co.uk)  
[www.kilworthmachinery.co.uk](http://www.kilworthmachinery.co.uk)

**STANDARD TRANSPORT BOX OPERATORS MANUAL**

Please Read This Manual Before Use And Keep Safe For Future Reference.

Incorrect use or mishandling of the Implement can endanger the operator or persons and animals in the vicinity of the machine.

Youths under the age of 16 must not use this Implement and **NEVER DISTRACT ANYONE WHO IS USING A MACHINE.**

**General Safety Operation;**

**KEEP** a safe distance of 5 mtr between people and animals whilst in operation

**ENSURE** correctly attached/detached to 3 Point Linkage on stable and level surface

**NEVER** attach to a tractor that cannot cope with the capacity of the Box

**NEVER** attempt to manually move Implement and take special care when removing the door

**NEVER** operate on ground that may render Tractor unstable and take care on sloping ground

**ALWAYS** safely store Trip Rope before detaching Box from Tractor

**ONLY** attach/detach Implement to Tractor using **ONE OPERATOR** making sure no one else is in the vicinity

**ALWAYS** ensure Trip Mechanism is securely closed before attaching/detaching Implement

**DO NOT USE THE TRANSPORT BOX FOR TRANSPORTING PEOPLE OR ANIMALS**

**KEEP** limbs well away from moving parts and from between Hitch and Main Body

**NEVER** allow children to play around Tractor or Machinery

**GENERAL OPERATION:**

Only intended for use on a Tractor, attempts to attach to any other type of vehicle must not be made

**NEVER** use incorrectly sized Lift Arms or Top Link Pins

Ensure Tripping Rope can be operated safely from the Tractor Cab and allows for free movement of the Implement for Max. Lift and Min. Lift so that there is no possibility of Slack Rope becoming entangled risking Life or Limb.

**REMOVE** Safety Bolt before using Box, Tip by tripping release mechanism by pulling rope.  
Lower To Floor To Reengage Catch

**MAINTAINENCE:**

Lower to floor to carry out work

**Disengage** Drive System, apply handbrake and stop engine prior to maintaining, servicing, cleaning or repair work.

**ALWAYS** remove ignition key

Oil Hinges frequently and periodically check for damage that may affect safe operation of machine

Always ensure warning signs are kept clean and in good condition

**MAX LOAD CAPACITY:**

4ft Box - 250 Kgs  
5ft Box - 350 Kgs  
6ft Box - 500 Kgs


---

**EU CERTIFICATE OF CONFORMITY**

**CONFORMING TO EC Machinery Directive 98/37 EC**

We;

**Beaconsfield Products (Halesowen) Ltd  
Upper Works, Foxoak Street, Cradley Heath  
West Midlands B64 5DE**



**Declare in sole responsibility, that the product**

**Type; Standard Transport Boxes; 4ft, 5ft, 6ft**

**To which this certificate applied, conforms to the basic safety and health requirements  
Of the EC Machinery Directive 98/37 EC, and the Transposed Harmonised Standards:  
BS EN 1553 (2000)**

**Robert B Taylor  
Managing Director**

---